

# Gigabit Ethernet Switch for Industrial Fiber Ring Application

# MICROSENS

## General

Ethernet has been used in the controlling level of industrial applications for many years. Ethernet is continuing to beat the field bus technologies used to date in coupling equipment controls, sensors and actors. Process error-tolerant network components are absolutely essential because the network availability has a direct effect on production.

It is precisely to prevent this that MICROSENS has developed a mechanism for which a patent is pending that enables the Ethernet network to be reconfigured within milliseconds if an error occurs.

The switches can be configured and monitored either by SNMP or a PC-based management tool NMP (Network Management Platform). In addition to the NMP all statuses are displayed web based using an integrated HTTP server.

In addition to the two 1000Base-SX/LX fiber connections for chain linking several industrial switches, the MICROSENS industrial switches also offer seven 10/100Base-TX connections for linking such Ethernet terminals as machine controls, network uplinks, consoles and other network participants and one 10/100/1000Base-T port for a central uplink connection.

In an extended version this switch is available with a third optical fiber port (1000Base-X). This port can be used alternative to the 10/100/1000Base-T port.

For particularly demanding uses, the industrial switches are designed in a suitably robust construction with an integrated clamping device for direct assembly on 35 mm DIN rails. The devices meet the requirements for IP protection class 30 and are also designed for a larger temperature range.

The power supply of the devices is done by an external, central power supply unit. With the second power input the device can be supplied with redundant power. All electrical ports are either galvanic isolated or equipped with an effective over voltage protection.




Fig. 1: Gigabit Ethernet switch for fault tolerant fiber rings

## Technical specifications

<b>Type</b>	Manageable Gigabit Ethernet switch with 1x 10/100/1000Base-T, 7 x 10/100Base-TX and 2 x 1000Base-SX/LX uplink for industrial fiber ring	
<b>Fiber type</b>	Multimode 62,5/125 or 50/125µm (1000Base-SX), Single mode 9/125µm, duplex (1000Base-LX)	
<b>Cable type</b>	Shielded Twisted Pair cable, 100 Ohm, Category 5, Pinout RJ45-ports auto crossing	
<b>Data rate</b>	10, 100 or 1000 Mbps	
<b>LED displays</b>	<i>Port 1-8</i> <i>G1</i>	Link (on) and activity (flashing) of the TP ports Green: Copper port 1 with Gigabit Ethernet speed Orange: Third optical fiber port active, copper port 1 without function (optional)
	<i>Port 9-10</i> <i>P1</i>	Link (on) and activity (flashing) of the fiber ports Green: Main Power Supply active Orange: Main Power Supply missing
	<i>P2</i>	Green: Backup Power Supply active Orange: Backup Power Supply missing
	<i>Ring</i>	Switch configured for ring mode
	<i>RM</i>	Ring Master (only in ring mode)
	<i>Alarm</i>	Fiber link interrupted or Power Supply problem
<b>Mounting</b>	35 mm hat rail, according DIN EN 50 022	
<b>Power supply</b>	18 - 36 V DC (optional 48 V DC) / max. 500 mA by external power supply connections with screw terminals, redundant ports	
<b>Power consumption</b>	typ. 8 Watt	
<b>Dimensions</b>	50 x 108 x 116 mm (w x d x h)	
<b>Operating temperature</b>	-20°C to 60°C	
<b>Storage temperature</b>	-20°C to 80°C	
<b>Rel. humidity</b>	5% to 90% non condensing	
<b>Management</b>	- Status information via web based management (http-Server) or support of SNMP - Configuration via PC based management tool (NMP)	

## Optical parameter

<b>Multimode</b>	<i>min. distance:</i>	550 m (full duplex, 50/125µm)
	<i>Output power:</i>	-10 dBm
	<i>Sensitivity:</i>	-20 dBm
	<i>Wavelength:</i>	850 nm
<b>Single mode</b>	<i>min. distance:</i>	10 km (full duplex)
	<i>Output power:</i>	- 8 dBm
	<i>Sensitivity:</i>	- 22 dBm
	<i>Wavelength:</i>	1300 nm

## Mounting

The switch is housed in a solid metal box with an integrated fixture for the installation on standard 35 mm DIN EN 50 022 rails.

The fixation of the MICROSENS switch on the rail is done with a locking pin that can be opened from the bottom side. If multiple devices are mounted in line, a minimum space of 20 mm should be kept between the devices, to ensure a sufficient heat dissipation.

## Switch Features

The integrated switch has a store-and-forward architecture and can transmit all packets non-blocking between the five ports at full wire speed. For data buffering the switch incorporates 1MBit of memory.

Up to 4096 different MAC addresses can be stored simultaneously in the internal switch address tables. An automatic aging mechanism updates the tables max. 5 min. after the last reception of data.

## Twisted Pair Connections

The integrated auto-crossing function of all Twisted-Pair ports makes the use of crossed patch cables unnecessary. The switch automatically detects the pinout of the connected cable and adapts the port accordingly. For all connections standard 1:1 Twisted Pair cables can be used.

The Autonegotiation mechanism detects automatically the speed and transmission mode (full or half duplex) between connected ports. A manual configuration is not required.

## Power supply

The power supply is done by an external power supply with an output voltage of 24 V DC. This power supply is not included at delivery, but can be ordered separately (MS700405). The connection is done by the pluggable screw terminals on the top of the device. The connection of a redundant power supply can be done by the second screw terminal.

## Management

The integrated http server offers to show status information by using a standard internet browser. A special configuration is not necessary. Additional to the web based management the switch offers a MIB to be used in all standardized Network Management Systems (NMS) supporting SNMP protocol.

With the PC based management tool NMP it is possible to configure all ports of the switch manually.

With this tool it is also possible to do the initial TCP/IP setting (IP address, Gateway etc.). This configuration can be changed afterwards using the TCP/IP protocol.

The management information are available inside of the network (inband management). A special connection is not necessary. Due to this all four twisted pair ports are available to connect other devices.

With the deactivation of the autonegotiation function of the twisted pair ports the configuration of the speed to 10 or 100 Mbit/s and full or half duplex mode is done manually.





Fig. 2: Network Management Platform (NMP).

## Ring Function

The two fiber ports of the device can be used to build up a ring structure. Ring structures are commonly used in industrial and telecommunication environments as they give redundant protection against failures at minimum cabling expense.

In normal operation the ring connection is logically interrupted by monitoring device (switch configured for Ring Master mode). In case of failure (broken connection or switch damage) the logically interrupted connection is activated by Ring Master.

A big advantage of this solution is, that no additional central device is necessary for the redundancy feature. Even if the ring master itself fails, the interruption of the ring stays at this location.



Normal operation status

Data transmission in failure status

## Ring Mechanism

The MICROSENS patented protection mechanism supports the fast reconfiguration of the data transmission in case of failure of one fiber segment. This function is a fixed feature of the industrial switch. During this operation one switch is having the manager function, all other switches are normal ring switches.

Each switch is monitoring the status of the connected fiber segment. In case of failure the connected switch forwards this information to the ring manager. The ring manager terminates the interruption of the ring immediately. The data is transmitted in all directions then. This fast signaling a fast failure detection within a few milliseconds (depending on the ring size).

## Ring Configuration

The configuration of the operating mode for the ring application is done with the Network Management Platform (NMP).

At the menu point Hardware Setting it is possible to select the two modes master or slave. The switch which is configured in master mode is doing the ring manager functions to avoid the multiplication of the data.

If one connection or one device fails this information is forwarded to the ring manager (master) by a special protocol. The ring manager keeps the operation of the complete segment up.

Advantage of this solution is that the ring manager itself has not to be redundant, because if the manager fails the data can not be multiplied. The segments stays under operation.

To avoid that the signaling in case of failure has no affect on other rings, it is possible to define different rings with numbers from 0 to 255 by the network management.

All switches with ring functionality are having the management features included and are offering the detection and signaling of any failure.

With this concept a limitation in regards to the maximum ring length is not given.


Best practice is to install the devices in their original position and to open the cabling in one position. For further configuration a PC with the latest version of the MICROSENS NMP running is required. The ring is configured in 4 basic steps:

- Assigning an initial IP-address to each ring switch
- Configuring all switches as rings slaves
- Configuring one switch as ring master
- Physically close the ring

### Step 1: Assigning an initial IP-address to each ring switch

To assign IP address you should use MAC-based Auto-Discovery function from NMP. This function allow you to search MICROSENS switches without IP address assigned or with IP address which doesn't belong to your network (it searches also switches already configured). MAC Discovery Function searches devices only in your broadcast domain. (broadcast domain - The portion of a network that is reachable by a network broadcast)


You can apply new IP address by right mouse click on the device name in the tree view, and choose "IP Settings" from pop up menu.



Pressing the 'Apply' button applies the entered values to the current device in configuration mode.

### Step 2: Configuring all switches as ring slaves

In order to see all initialized switches in the MICROSENS Network Management Platform, the Auto Discovery process must be started by pressing the corresponding toolbar-button. Now all switches should appear in the device list window. For configuration of the switches, right click on one switch in the device list and choose 'Device settings' from the context menu.




The "Device settings" window has a section for the ring-configuration. Three values can be set:

- Ring mode enable/disable  
This checkbox activates the ring mode – select 'Enable'
- Ring Master/Ring Slave  
This radio buttons configure the ring mode – select 'Slave'
- Ring Number  
To prevent interference in multi ring environments, each ring must have a unique ID-number. Enter '1' or any other number between 0 and 255.

Once these settings are made, they must be applied to all devices in the ring. Choose 'Apply new configuration'. Now all ring switches are set to ring mode with slave functionality.

### Step 3: Configuring one switch as ring master


Reopen the "Device settings" window by right click in the device list on the switch that shall be the ring master device and select the 'Master' button in the ring mode window. Now one switch in the ring is configured as master, all others are configured as slaves.



### Step 4: Physically close the ring

If all devices are configured correctly, the ring can be closed physically by connecting the segment left open during the configuration cycle.

The ring configuration is now completed. As the ring behaviour works fully automatic, no more interference with the switches during operation is required. Upon a ring failure, the master will reconfigure the ring. When the ring is closed again, the master will automatically fall back into normal operation mode.



## Spanning Tree Protocol

The Spanning Tree Protocol is a network protocol that ensures a loop free topology. Spanning tree allows a network design to include redundant links to provide automatic backup paths if an active link fails, without the danger of bridge loops, or the need for manual enabling/disabling of these backup links. The Rapid Spanning Tree Protocol (RSTP) is an evolution of the Spanning Tree Protocol and provides for faster spanning tree convergence after a topology change.

MICROSENS Gigabit Ethernet Switch support both of these protocols (STP and RSTP), and their configuration is done with the Network Management Platform (NMP). You can configure Spanning Tree Protocols by right mouse click on the device name in the tree view, and choose "STP" from popup menu.



## STP and RSTP - main parameters

STP Settings 192.168.0.103

Device configuration

Spanning tree function: RSTP

Bridge priority: 32768

Bridge hello time (sec) [1..10]: 2

Bridge max. age (sec) [6..40]: 20

Bridge forward delay (sec) [4..30]: 15

Transmit hold count [1..10]: 6

STP Port settings

No.	enable	Priority	Admin path cost (0 = auto)	Admin point to point	Admin edge port	Migration
1.	<input checked="" type="checkbox"/>	128	0	auto	<input type="checkbox"/>	Check
2.	<input checked="" type="checkbox"/>	128	0	auto	<input type="checkbox"/>	Check
3.	<input checked="" type="checkbox"/>	128	0	auto	<input type="checkbox"/>	Check
4.	<input checked="" type="checkbox"/>	128	0	auto	<input type="checkbox"/>	Check
5.	<input checked="" type="checkbox"/>	128	0	auto	<input type="checkbox"/>	Check
6.	<input checked="" type="checkbox"/>	128	0	auto	<input type="checkbox"/>	Check
7.	<input checked="" type="checkbox"/>	128	0	auto	<input type="checkbox"/>	Check
8.	<input checked="" type="checkbox"/>	128	0	auto	<input type="checkbox"/>	Check
9.	<input checked="" type="checkbox"/>	128	0	auto	<input type="checkbox"/>	Check
10.	<input checked="" type="checkbox"/>	128	0	auto	<input type="checkbox"/>	Check

Apply new configuration      Close

- **Spanning tree function:** you can choose protocol (STP, RSTP) or disable function
- **Bridge priority:** A value used to identify the root bridge. The bridge with the lowest value has the highest priority and is selected as the root. The value must be a multiple of 4096 according to the protocol standard rule.
- **Bridge hello time:** The time that controls switch sends out the BPDU packet to check RSTP current status. Enter a value between 1 through 10.
- **Bridge max. Age:** The number of seconds a bridge waits without receiving Spanning-tree Protocol configuration messages before attempting a reconfiguration. Enter a value between 6 through 40.
- **Bridge forward delay:** The number of seconds a port waits before changing from its Rapid Spanning-Tree Protocol learning and listening to STP states to the forwarding state. Enter a value between 4 through 30


You can configure path cost and priority of every port.

- **Priority:** you Decide which port should be blocked by priority in LAN. Enter a number 0 through 240. The value of priority must be the multiple of 16
- **Admin path cost:** The cost of the path to the other bridge from this transmitting bridge at the specified port. Enter a number 1 through 200000000
- **Admin point to point:** Some of the rapid state transactions that are possible within RSTP are dependent upon whether the port concerned can only be connected to exactly one other bridge (i.e. it is served by a point-to-point LAN segment), or can be connected to two or more bridges (i.e. it is served by a shared medium LAN segment). This function allows the P2P status of the link to be manipulated administratively. True is P2P enabling. False is P2P disabling.
- **Admin edge port:** The port directly connected to end stations cannot create bridging loop in the network.

## Port Access Control

Port-based network access control makes use of the physical access characteristics of IEEE 802 LAN infrastructures in order to provide a means of authenticating and authorizing devices attached to a LAN port that has point-to-point connection characteristics, and of preventing access to that port in cases which the authentication and authorization fails. A port in this context is a single point of attachment to the LAN infrastructure.

MICROSENS Gigabit Ethernet Switch supports Port Access Control, and the configuration is done with the Network Management Platform (NMP). The configuration is possible by right mouse clicking on the device name in the tree view, and choosing "Port Access Control" from popup menu.



## Port Access Control – Basic settings

Port Access Control - 192.168.0.26

Basic settings

Port access control enabled:

Mode for unauthorized ports:

Default VLAN for unauthorized ports:

Port no.	Mode	Host No.	MAC Locking settings		
			enable	learn	MAC address (xx-xx-xx-xx-xx-xx)
Port 1:	<input type="text" value="force-authorized"/>	1.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="text" value="00-00-00-00-00-00"/>
		2.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="text" value="00-00-00-00-00-00"/>
		3.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="text" value="00-00-00-00-00-00"/>
		4.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="text" value="00-00-00-00-00-00"/>
Port 2:	<input type="text" value="force-authorized"/>	1.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="text" value="00-00-00-00-00-00"/>
		2.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="text" value="00-00-00-00-00-00"/>
		3.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="text" value="00-00-00-00-00-00"/>
		4.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="text" value="00-00-00-00-00-00"/>
Port 3:	<input type="text" value="force-authorized"/>	1.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="text" value="00-00-00-00-00-00"/>
		2.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="text" value="00-00-00-00-00-00"/>
		3.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="text" value="00-00-00-00-00-00"/>
		4.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="text" value="00-00-00-00-00-00"/>
Port 4:	<input type="text" value="force-authorized"/>	1.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="text" value="00-00-00-00-00-00"/>
		2.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="text" value="00-00-00-00-00-00"/>

max. MAC count -> 1

Apply new configuration Close

- **Port access control enabled:** you can enable or disable this function.
- **Mode for unauthorized ports:** Settings mode for unauthorized ports. One of three action can be set: blocking, using default VLAN or sending only notification.

## Port Access Control – Port settings

Ports can be in one of five authorization modes.

- **IEEE 802.1x Authentication:** This mode is the normal 802.1X mode. A port sends EAP packets to the supplicant and will not become authorized unless it receives a positive response from the authentication server.
- **Force-authorized:** This mode, is the default mode. In this mode, a port is always authorized and does not require any messages from either the supplicant or the authentication server. Force-authorized mode is used when you do not want to run 802.1X on a particular port. This is typically the case when connecting

to another switch, a router ,or a server, and also when connecting to clients that do not support 802.1X.

- **Force-unauthorized:** This mode prevents a port from becoming authorized even if the user has the appropriate credentials. This mode essentially disables the port from use by any user or device.
- **RADIUS MAC Authentication:** RADIUS protocol is used to MAC Authentication.
- **MAC Locking:** This mode gives possibility to authentication from up to 4 users per port on the basis of the MAC – addresses.

## Safety Notes

**WARNING:** Infrared radiation as used for data transmission within the fiber optic, although invisible to the human eye, can nevertheless cause damage.

To avoid damage to the eyes:

- never look straight into the output of fiber optic components – danger of blinding!
- cover all unused optical connections with caps.
- commission the transmission link only after completing all connections.

The active laser components used with this product comply with the provisions of **Laser Class 1**.

**DANGER:** Conductive components of power and telecommunications networks can carry dangerously high voltage.

To avoid electric shock:

- Do not carry out installation or maintenance work during lightning storms.
- All electric installations must be carried out in accordance with local regulations.

## Order Information

Art.-No.	Description	Connectors
MS650850M	Gigabit Ethernet Switch with ring function 1x 10/100/1000Base-T, 7x 10/100Base-TX, 2x 1000Base-SX, ST multimode 850 nm	4x ST 8x RJ-45 2x Power, 1x Alarm
MS650851M	Gigabit Ethernet Switch with ring function 1x 10/100/1000Base-T, 7x 10/100Base-TX, 2x 1000Base-SX, SC multimode 850 nm	4x SC 8x RJ-45 2x Power, 1x Alarm
MS650852M	Gigabit Ethernet Switch with ring function 1x 10/100/1000Base-T, 7x 10/100Base-TX, 2x 1000Base-LX, SC single mode 1310nm, 10 km	4x SC 8x RJ-45 2x Power, 1x Alarm
MS650861M	Gigabit Ethernet Switch with ring function 1x 10/100/1000Base-T, 7x 10/100Base-TX, 3x 1000Base-SX, SC multimode 850 nm	6x SC 8x RJ-45 2x Power, 1x Alarm
MS650862M	Gigabit Ethernet Switch with ring function 1x 10/100/1000Base-T, 7x 10/100Base-TX, 3x 1000Base-LX, SC single mode 1310nm, 10 km	6x SC 8x RJ-45 2x Power, 1x Alarm

## Accessories

Art.-Nr.	Description	Connectors
MS700420	Hat-rail power supply 24 Watt 24 V / 1,0 A, wide range input 85-264 VAC	In: 3-pin Out: 2-pin
MS700421	Hat-rail power supply 60 Watt 24 V / 2,5 A, wide range input 85-264 VAC	In: 3-pin Out: 5-pin
MS700422	Hat-rail power supply 120 Watt 24 V / 5 A, wide range input 85-264 VAC	In: 3-pin Out: 5-pin
MS700430	Hat-rail power supply 60 Watt 48 V / 1,25 A, wide range input 85-264 VAC	In: 3-pin Out: 5-pin
MS700434	DC/DC hat-rail power supply 24 Watt 24 V / 1,0 A, wide range input 18-75 V DC	In: 3-pin Out: 2-pin

MICROSENS reserves the right to make any changes without further notice to any product to improve reliability, function or design.  
MICROSENS does not assume any liability arising out of the application or use of any product. 1209/Helmd

[www.microsens.com](http://www.microsens.com)